

SOUTH BRANCH

Station	Bearing
236+52	
241+00	S. 45° 53' E.
242+00	S. 69° 32' E.
246+00	S. 37° 54' E.
248+00	S. 47° 10' E.
249+24	S. 73° 25' E.
251+75	N. 85° 35' E.
252+80	S. 69° 35' E.
257+66	S. 27° 30' E.



SECTION 6-T. 4 N. R. 1 W. S. L. M.