
11
12
14
13
23
24
26
25
W. as estab.
= cor. as set by Sam. Tally & Hurt.
= cor. as set by Sam.
= cor. as set by Same
= cor. as estab by mrs.
= cor. as set by mrs.
= cor. set by Sam.
= old Cor.
= cor. as estab by mrs
= det Sec. Cor
= Cor. as estab by mrs
= cor. as set by Sam. Correction Line
= cor. as set by mrs
= point marked to
cor. W of cor. on E. bdy
Pinta
sectional
W. 5280.
E 5280.
5037.
5243.
5167.
5280.
5620
3.5
3.5 Ft.
N 89° 14' E random
S 89° 15' E random
S 89° 02' E
N 0° 10' E
N 0° 11' E
E 2644 Tp. 4.
S 0° 10' W
N 0° 09' E
S 0° 08' W
S 0° 11' W
S 0° 09' W
E 2644 Tp. 3.
N 0° 09' E
S 0° 09' W
S 0° 08' W
S 0° 11' W
S 0° 09' W
E 2644 Tp. 2.
N 0° 09' E
S 0° 08' W
S 0° 11' W
S 0° 09' W
E 2644 Tp. 1.
N 0° 09' E
S 0° 08' W
S 0° 11' W
S 0° 09' W
E 2644 Tp. 4.
N 0° 11' E
S 0° 10' W
N 0° 10' E
S 0° 11' W
S 0° 09' W
E 2644 Tp. 3.
N 0° 09' E
S 0° 08' W
S 0° 11' W
S 0° 09' W
E 2644 Tp. 2.
N 0° 09' E
S 0° 08' W
S 0° 11' W
S 0° 09' W
E 2644 Tp. 1.
N 0° 09' E
S 0° 08' W
S 0° 11' W
S 0° 09' W